



## Bell Tent UK

### How to fit your Tipi Stove from Bell Tent UK

Hello

Thanks for buying one of our handmade (in the UK) Bell Tent Tipi Stoves. This stove is designed to fit one of our 5 metre tipis and should allow you to extend your camping season.

Any questions feel free to call us on 07830 355994 or email [info@belltent.co.uk](mailto:info@belltent.co.uk)

### How to Fit the Bell Tent UK Tipi Stove Kit.

#### **Tools needed:**

- A screw driver for the flue kit connectors

#### **Assembling the Stove.**

Your Bell Tent UK Tipi Stove has been designed to pack down small for transport and should only take a couple of minutes to put together.



Turn the stove upside down and screw on the 4 legs onto the bottom of the stove. Flip the stove over and put it on the bottom plate. Now it's time to connect the parts of the flue together



Start with the top piece with the double skin heat protector and make sure you have correct end with the cap so the sheath doesn't slip down when the piece is vertical. This then sets you up for the rest of the build.



Take a clamp and screw the two parts together  
(new version uses ski boot like clamps so you don't need the crew driver.)



On the next joint use the clamp with the securing chain and attach in the same way



Repeat with the final shortest piece so you have a long securely attached flue like the image above.


Now it's time fit the flue to the tent.

Make sure you've correctly erected the tipi but leave the straps around the pegs loose to make it easier to drop the main pole.



Get the flue lined up outside the door and then drop the main pole out of the door so it ends up next to the flue. Now walk back into the tent holding both the pole and flue and push the flue through the webbing under the slit in the cap.

Go back outside and fit the cap (or even better stay inside and get someone else to do it).



Now raise both the pole and the flue back to vertical and make sure you slide the double skin section is over the webbing.

Secure the chain round the main pole and then get the stove and bottom plate and drop the bottom of the flue into the top of the stove.



Job done, enjoy your toasty tipi

## **Putting your Stove away.**

Very quick and easy, just follow the Assembly Instructions backwards but here a few tips:

- Make sure everything has cooled down enough and use water to cool if not.
- The easiest way to empty the ash is to remove the protection plates and legs and turn the whole stove upside down. (Be sure to empty in a safe place and make sure the ash and embers are truly out by pouring some water over them. Be responsible and leave no trace!)

### **NB. Disclaimer.**

We have to put this as you are literally playing with fire.

Bell Tent UK takes no responsibility for the misuse of this product or for any damage caused by using it. Bell tents from us are not pre fire proofed so if you feel that is necessary make sure you do it yourself. This stove is a sealed unit so with some common sense you can protect yourselves. We recommend that you always put a mat or piece of carpet under your stove as sparks will go straight through the ground sheet.

Always have a means of putting out a fire within reach and always make sure the fire is put to bed before you are.

Our Bell Tent UK Stove is tested and rated to 2.5kw. This is a good temperature to warm up a tent without becoming a furnace. Do not use artificial means to make your stove burn hotter (like constantly blowing or fanning the flares to create a furnace). You risk damaging the stove kit and even your tent.

If you want to circulate the hot air around your tent consider our Eco heat powered fan which can be found on the website – [www.belltent.co.uk](http://www.belltent.co.uk)



As we said before please contact us with any questions and also if you have a good idea or a better way of doing something.

We hope you get loads of enjoyment out of your Bell Tent UK Tipi Stove and that it extends your camping season!